
MAINSAIL MEASUREMENT FORM

Mast Bend Measurement.

We require the following information and measurements to enable us to ensure a perfect fit for your new sail. Please note that if asked for max dimensions or max hoist, we will deduct a suitable amount for stretch. Do not measure sails using a rope. It is advisable to use a long fiberglass tape.

CUSTOMER NAME:		
BOAT TYPE:	RIG TYPE: FRACTIONAL OR MASTHEAD	
HOW TO COMPLETE THIS FORM Either measure existing sail or enter rig dimensions EXISTING SAIL Pull sail tight for measurement. Ensure each length is a straight line measurement from head to tack and clew. MAX LUFF MAX LEECH MAX FOOT m m m	Luff measured from top of boom to top of head E Foot measured from back of mast to centre bolt	
Attach tape measure to mainsail halyard and maximum hoist to top block.		
1. To measure max Luff: P (we will deduct stretch) Take measurement to top of boom for Luff. 2. To measure max Leech: (we will deduct stretch) Take measurement to desired clew position or black band. (Only necessary if boom end needs to be raised to allow for sprayhood or other).	TACK DETAILS (refer to diagram above) 1. Tack Back (A) Measure from back of mast to centre of tack pin. 2. Tack Up (B) Measure from top of boom to centre of tack pin. 3. Sail insertion height. From top of boom to bottom of mast gate.	
3. To measure Foot (E) Drop halyard, remove tape measure and measure length of boom from back of mast to black band or clew position.	CLEW DETAILS (please tick option 1, 2 or 3)	
4. To measure Backstay distance D Measure from back of mast to backstay.	1. Standard is stainless steel ring only 2. S/S ring with velcro strop to go around boom	
5. To measure Mast Bend. With the main halyard pulled tight down to the intersection of boom and mast, look up the mast to determine the mast bend. Estimate the distance between halyard and aft face of mast about ½ way up and record this as the	3. S/S ring with clew slide for boom groove. Specify slide number and dimensions as per diagram on page 2	

MAINSAIL MEASUREMENT FORM



LUFF ATTACHMENT

Specify luff slide style 1,2,3 or other (see diagrams) OR provide measurements and photo.

- 1			
Existing luff slide	es: Part Number.		
Measurements of existing luff slide			
A Width	B Neck	C Length	
mm	mm	mm	
Or Measurements of mast track			
A Internal Width	B Internal Depth	C Track Opening	
mm	mm	mm	

FOOT FINISHING

1. Loose foot only (clew side already in place) (please tick)	
2. Loose foot with clew side (please tick)	
3. Bolt rope. (please indicate size in mm)	mm

Rutgerson Clew Block (60mm) 4 Vertical Battens Logo and Numbers (Bavaria 30 Cruiser) arctic blue 6.11 Warp Drive Tri Radial

HOW TO MEASURE FOR A FURLING MAINSAIL

Attach tape measure to bottom of head swivel and pull to max hoist and lock halyard off.

- 1. Max Luff: Measure to tack hook or shackle in mast.
- Max Leech: Make sure boom is clear of bimini or set boom as you would sailing. Measure to max outhaul position of block.
- **3. Outhaul:** Secure measure to tack hook or shackle. Run tape along boom and measure to max outhaul position.
- 4. Luff tape diameter mm
- 5. Clew block or Standard clew ring (circle)